UNDERLAY CC21 Comfort Line Floating Floors



RECYCLED FOOTFALL NOISE REDUCTION UNDERLAY

High Durability and Long Term Resilience Increases Floor Thermal Insulation Recycled and Sustainable Product Easy to Handle and Install

PRODUCT DESCRIPTION

Agglomerated Cork and Recycled Rubber Underlay for Footfall Noise and Thermal Insulation of Floating Floors.

(ISO 140 & 717)

ΔLw = 19dB (EPH MFPA Leipzig P4.2/08 - 176)

Loudness Reduction = 25.1% (EPH Test Report 268139)

THERMAL PROPERTIES (ISO 8301)

Thermal Conductivity: 0,075 W/m°K

Thermal Resistance: 0,027 m^{2°}K/W

PACKAGING*

1m x 10m x 2mm * Others sizes available upon request



Specific Weight: 550-650 Kg/m³ Tensile Strength: > 600 KPa Compression: 15% Recovery: > 90% Durability: Lifetime of the Building











RECYCLED FOOTFALL NOISE REDUCTION UNDERLAY

General installation instructions

The following installation instructions are recommended by Amorim Cork Composites, but are not intended as a definitive project specification. They are presented in an attempt to be used with recommended installation procedures of the flooring manufacturers.

Room conditions

Temperature > 10°C / Room moisture content < 75%.

Subfloor

All subfloor work should be structurally sound, clear and level. The moisture content of the subfloor should not be more than 2.5% (CM) by weight measured on concrete subfloors.

Insulation vapour barrier

A p.e. insulation vapour barrier covering the entire flooring area, minimum 50mm wide vertically around the perimeter of the entire floor MUST be installed prior to the AcoustiCORK C21. Install by overlapping (minimum 100mm) the p.e. foil, and use an adequate tape to adhere/fix it, if necessary. After completion, p.e. foil should cover the entire concrete area without gaps. Never mechanically fasten the p.e. foil barrier with screws, nails or staples as this will severely diminish the performance of the insulation barrier.

Installations instructions for AcoustiCORK C21

Unpack the AcoustiCORK C21 at least 24h before the installation and store it in the room where the installation will take place. Cut the AcoustiCORK C21 to desired length and install directly over the entire floor pulled 30mm up the walls with crown of the rolled materials up (AcoustiCORK label side down), removing all traped air. After completion, the AcoustiCORK C21 should cover the entire flooring area without gaps and with joints butted tight and preferably taped.

Final flooring

Always follow manufacturers recommended installation instructions.

Important notes

Never mechanically fasten the AcoustiCORK C21 to the flooring floor as this will severally diminish its acoustical value.

For detailed installation instructions, please contact us.



União Europeia Fundo Europeu de

www.acousticork.eu

HEAD OFFICE Rua de Meladas, 260 - Apartado 1 4536-902 Mozelos VFR - Portugal T: +351 22 747 5300 / F: +351 22 747 5301 E-mail: acousticork.acc@amorim.com www.corkcomposites.amorim.com

